Tel: (01924) 820003
Fax: (01924) 829529
www.renotex.co.uk

METHOD STATEMENT

RENOTEX ROLLERCOAT

1. The rendered surface must have cured for 7 - 10 days.
The appearance of the render must be dry.

2. Mask up all areas not to be coated, i.e. gutters, windows, doors etc.

3. Apply 1st coat of Renotex Rollercoat smooth thinned by up to 10% using manufacturers' thinners.
Apply by sheepskin or simulated sheepskin roller.
1st coat must be left to cure overnight.

4. Apply 2nd coat of Renotex Rollercoat by roller thinned 5% to 10%. **

5. Coverage for two coats is 2 sq metres per litre.

** Please note if Hi-Build is used for the 2nd coat add same amount of thinners and apply with honey-comb sponge roller. Coverage will be 1 sq metre per litre.

This method statement is to be used in conjunction with the application guidelines on the reverse of the Renotex Rollercoat work-sheet.

Preparation	**Brick**			**Render**		**Blockwork**	**Pebbledash**	**Tyrolean**	**Concrete**	**Metal**	**Asbestos Roof Internal**
	New	**Old**	**Pntd**	**New**	**Pntd**						
Brush down to remove dust etc.	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓
Stiff brush to remove flaking paint, dirt etc.			✓		✓	✓	✓	✓			
Power wash if necessary to remove flaking paint, dirt etc.			✓		✓						
Check adhesion of render - hack off where necessary and repair.			✓		✓		✓	✓			
Hairline cracks to be filled with Flexible Filler.					✓		✓	✓			
Hack off and make good blown Pebbledash or Tyrolean.							✓	✓			
Wire brush loose & damaged pointing from brickwork joints and make good if required.		✓	✓			✓					
Treat algae and lichen growth with Reno Anticide Wash.		✓	✓		✓	✓	✓	✓	✓		
Reface spalling and crumbling brickwork if required.		✓	✓			✓					
Primer for use on friable or porous surfaces. Prime with 10% dilution of Rollercoat and approved solvent.	✓	✓	✓	✓	✓	✓	✓	✓	✓		